



# File Locations

---

Below are the file locations for the AutoCAD® templates and supporting files:

## Pipes Catalog

Copy the CofC Pipes Catalog folder to the default Pipe Catalog folder (C:\ProgramData\Autodesk\<Version of AutoCAD>\enu) and ensure that this folder is selected in Set Pipe Network Catalog

or

Copy the CofC Pipes Catalog folder to a user defined folder and ensure that this folder is selected in Set Pipe Network Catalog

## Drawing Templates

Copy the .dwt files to the default Drawing Template folder (C:\Users\<username>\appdata\local\autodesk\<Version of AutoCAD>\<RXX.X>\enu\template)

or

Copy the .dwt files to a user defined folder and ensure that folder is added to the Drawing Template File Location in Options

## Figure Prefix Database

Copy the CofC.fdb\_xdef file to the default Figure Prefix Database folder (C:\ProgramData\Autodesk\<Version of AutoCAD>\enu\Survey) and ensure that this file is selected as the Figure Prefix Database

or

Copy the CofC.fdb\_xdef file to a user defined folder and ensure that this file is selected as the Figure Prefix Database

## Linetype and SHX

Copy the .lin & .shx files to the default Support folder (C:\Users\<username>\appdata\roaming\Autodesk\<Version of AutoCAD>\<RXX.X>\enu\support) \*

or

Copy the .lin & .shx files to a user defined folder and ensure that folder is added to the Support File Search Path in Options

## Hatch Patterns

Copy the .pat files to the default Support folder (C:\Users\<username>\appdata\roaming\Autodesk\<Version of AutoCAD>\<RXX.X>\enu\support) \*

or



Copy the .pat files to a user defined folder and ensure that folder is added to the Support File Search Path in Options

## PlotCfgs

Copy the .ctb files to the default Plot Style Table folder

(C:\Users\\AppData\Roaming\Autodesk\

or

Copy the .ctb files to a user defined folder and ensure that folder is added to the Plot Style Table Search Path in Options

Copy the .pc3 file to the default Printer Configuration folder

(C:\Users\\AppData\Roaming\Autodesk\

or

Copy the .pc3 files to a user defined folder and ensure that folder is added to the Printer Configuration Search Path in Options

## Sheet Set Template

Copy the .dst file to the default Sheet Set Template folder

(C:\Users\\appdata\local\autodesk\

or

Copy the .dst file to a user defined folder and ensure that folder is added to the Sheet Set Template File Location in Options

**\* Note: the <RXX.X> folder does not apply to some vertical Autodesk programs such as Civil 3D.**